

#### INTRODUCTION

Thank you for purchasing the Nautilus dry herb vaporizer! It's the coolest, most distinctive dry herb vaporizer on the market – you'll be consuming in style! Nautilus features variable temperature control (300°F-435°F/149°C-224°C) so that you can dial-in the perfect temperature. You'll also enjoy the OLED display, which visualizes the battery level, temperature settings, session time, and more.

Please completely read these instructions to ensure you're aware of all features, functions and safety warnings. Failure to follow instructions may result in injury and may void your warranty.

To activate the 1 year warranty, register your purchase by scanning the OR code to the right with your phone, or by visiting: www.carrycipher.com/register



#### **Package Contents**

- 1x Nautilus dry herb vaporizer
- 2x Mouthpiece O-ring seals
- 1x Loading tool
- 1x Cleaning brush
- 1x Micro-USB charging cable
- 1x User guide

# TEMPERATURE BATTERY LEVEL BATTERY LEVEL PIPE ICON - HEATING UP OR BAKING MAX SESSION TIME MAX SESSION TIME 1 375°F 2 2 2 2 — ACTUAL TEMPERATURE SESSION TIME

**NAUTILUS FEATURES** 



**Initial Steps** 

Upon unboxing, Nautilus will be only minimally charged, so it's recommended to give the battery a complete charge before the first use. Once charged, it's recommended to set Nautilus to the highest temperature for one complete session, without any herb loaded, to burn off residual impurities from the manufacturing process.

**HOW TO USE NAUTILUS** 

#### How to Power ON and OFF

To turn Nautilus on, click the power button 5 times in rapid succession (i.e., within 2 seconds). The OLED screen will turn on, and the pipe image will start flashing with vapor to indicate it's heating up. To turn Nautilus off, repeat the same clicking of the power button 5 times.

#### **How to Change Temperature**

After turning Nautilus on, the chamber will heat to the previously set temperature (displayed on the OLED screen directly to the right of the battery level indicator). Upon unboxing, the initial set temperature is 375°F (190°C). Clicking the '-' or '+' button (any time power is turned on) will change the set temperature by 1°. The set temperature can be raised/lowered quickly by pressing and holding the appropriate button.

Nautilus will keep the current set temperature in memory until it's changed. The temperature units can be changed between "F and "C by pressing and holding the power button for 3 seconds.

## HOW TO USE NAUTILUS

**300°F-350°F**: Herb will be lightly toasted; flavor will be tasty; minimal vapor cloud; moderate cannabinoid/terpene vaporization.

**350°F-400°F**: Herb will be half baked; flavor will be richer; larger vapor cloud; most cannabinoids/terpenes will be vaporized.

**400°F-435°F**: Herb will be fully baked; flavor will be harsher; maximum vapor cloud and complete cannabinoid vaporization.

#### Loading the Chamber

What to Expect

Start by grinding your material to a medium-fine grind (this is an important step that greatly affects the quality of vaporization). For best results, fill the chamber at least halfway, or up to a maximum of just below the top edge of the chamber. Use the loading tool to gently pack/compress the material into the chamber. Reattach the mouthpiece.

# Consuming

After powering on Nautilus, the heat up process (-30-40 seconds depending on the set temperature) will be indicated on the OLED screen by flashing vapor above the pipe image, and the 'actual' temperature value (middle of OLED screen) will show an increasing value. When the set temperature is reached, the flashing vapor will stop. For best results: 1) wait ~5-10 seconds before starting to inhale to allow the herb time to start vaporizing: and 2) it's recommended to inhale with smooth. 2-3 second draws as if you're sipping hot tea/coffee. After the initial heat up time. Nautilus will operate for up to 5 minutes until automatically turning off. If more time is needed to consume all of your material, Nautilus can be turned on for one additional session.

**HOW TO USE NAUTILUS** 

**WARNING:** Avoid touching the silver ring, since it gets hot from the chamber during operation. Also, avoid placing any part of your hand over the chamber airflow holes near the mouthpiece, as this will significantly-degrade airflow and potentially cause overheating.

#### **CHARGING THE BATTERY**

Nautilus uses a Micro-USB charging cable, and should be connected to either a standard computer USB port, or a wall charger (must be 5V/1A). Charging time is approximately 1 hour. While charging, the battery level indicator on the OLED screen will repeatedly crawl from right to left until fully-charged. Once fully-charged, the battery level indicator will become solid.

**WARNING:** Do not connect to a USB car charger, as it may cause damage to the battery and void the warranty.

#### **CLEANING & MAINTENANCE**

#### Chamber

Before cleaning the chamber, make sure Nautilus is turned off and has cooled down for at least 5 minutes. After tapping out the herb loaded in the chamber, use the provided cleaning brush to clean remaining particles and residue from the chamber walls. Periodically, it's recommended to use a cotton swab (Q-Tip) dipped in 91% Isopropyl alcohol to gently rub on the chamber walls to remove residue buildup.

### **CLEANING & MAINTENANCE**

#### Chamber Cont.

After allowing the alcohol to dry completely, turn the device on, with the chamber still empty, and let it heat for one complete session with the mouthpiece removed to ensure all residual alcohol is burnt off.

**WARNING:** Do not use water or soap to clean the chamber, as it may leak inside Nautilus and damage the device, voiding the warranty.

#### Mouthpiece

After each use, it's recommended to clear particles from the mouthpiece screen (bottom side that faces the chamber) using the cleaning brush. Periodically, the mouthpiece should soaked in 91% Isopropyl alcohol for 20-30 minutes. Rinse with warm water and then let dry before using.

### **IMPORTANT SAFETY DISCLAIMERS**

Do not expose to extreme temperature, as this may cause the battery to overheat and catch fire.

Do not drop or submerge in any liquid.

Do not open the device or modify the electronics. Doing so will void the warranty.

Do not charge the device near a fire source or any flammable material.

Do not touch any part of the chamber for at least 5 minutes after use

#### Disclaimer

For adult use only (21+). Keep all parts away from children. Users of this device do so at their own risk. Cipher and its affiliates are not responsible for any damage or personal injury caused by inappropriate, incorrect or irresponsible use of the device. Nautilus is not a medical device and is not intended to diagnose, treat, cure, or prevent any type of ailment, disease, or other condition. Please consult a physician before using this device, especially if you have any type of serious medical condition, or if you are pregnant or breastfeeding, etc.

This device is designed for legal, leafy botanical material, and is not to be used with thick oils, tobacco or nicotine products of any kind.

### 1 YEAR LIMITED WARRANTY

Cipher will warranty Nautilus for a period of one (1) year to be free of defects in materials and workmanship under normal use from the date of purchase. All warranty claims require registration of the product and submission of proof of purchase. The warranty only applies to the original purchaser and is non-transferrable.

### Exclusions

The warranty does not apply when damage occurs due to the device being dropped, abused, submerged in liquid, altered, affected by a natural disaster, or misused in any way. The warranty does not extend to cosmetic marks, dents, chips, scratches, etc. Normal performance degradation of the battery life is not covered by the warranty.

ELEVATE YOUR EVERYDAY

ELEVATE YOUR EVERYDAY

@CARRYCIPHER.COM

Need Help?

Should you have any questions, or need help operating the device, you can email the Support Team at: Support@CarryCipher.com

CIPHER COPYRIGHT. ALL RIGHTS RESERVED.

6 7 8 9 10 B